Athletic Watch is your BEST fitness product that guides you to achieve your physical goal & healthy lifestyle.

HEALTH NOTICE

and cannot predict the intensity level that is safe for you. It is of heart related health problems. Before you begin any you have been inactive for a period of time, have a history of cardiac illness, smoke, have high blood pressure and/or are over-weight. If you use a pacemaker, do not use a heart rate monitor until you consult with your doctor

SPECIFICATIONS

Watch Receiver:

- O Heart Rate Range

- O Battery
- O Weight

Transmitter & belt:

- O Weight (including belt)

O Emitted Frequence

- O Adjustable Chest Belt

5KHz ±10%

3 volt lithium 2032 cell 4 oz.

±1 beat per minute

30 to 240 beats per minute

This product is for displaying heart rate during exercise only not intended for medical diagnostic purposes or for prevention exercise program, please consult your physician, especially if


- O Heart Rate Accuracy
- O Operating Temperature 0°C ~ 50°C O Storage Temperature -14°C ~ 70°C
- 3 volt lithium 2032 cell 30.6 grams

How to wear your Athletic Watch

The transmitter should be positioned right below the breasts / pectoral

The strap should be comfortable, but secure.





Note: Do not use Athletic Watch near high voltage power cables.

FEATURES: O Time of Day

- O Day / Date Calendar Stopwatch
- OLaps-30 LAPs
- O Current/ Average/ Max. HR display
- O Calories Burned for an Individual / Total Exercises O Up to 10m Depth Water Proof for All Water Sports
- O Wireless ECG Accurate
- O Large Easy-to-View LCD Display
- One-touch Button for Audible Alarm OFF
- O Ultra-Slim Ergonomic Chest Belt Transmitter
- O State-of-Art attractive Wrist Watch design
- Target Zone Setting w/ Audio-Visual Alarm (1 bpm increments)

Mode Change

Press "MODE" button to change mode.



3. Target Zone Setting

4. Laps-30 Laps

Record current HR, total exercise time and each Lap's time.



5. Max Heart Rate



7. Calories Burned


Date/Time Mode O Repeat 2 & 3 to set Month/ Date/ 12HR/ 24HR/ Hour/ Minute/

Second, and press"SET" to complete the setting.

Nightsight (Backlit Display Light)

Press the "Light" key to activate NIGHT SIGHT. To facilitate night time monitoring, the display will illuminate and the heart rate reading will "freeze" for 4 seconds.


Target Zone Setting



- key, the digits will adjust by 5 BPM increments.
- The heart watch automatically maintains a 10 BPM separation between the upper and lower target settings. Therefore, you may notice that the upper and lower settings move simultaneously whenever there is only a 10 BPM difference.

Measure Mode

Start STOPWATCH



Using the Stopwatch and Lap Record Features:

Starting the Stopwatch:

• Press the "Mode" Button 2 times to reach the Stopwatch display. O Press the "START/STOP" button that the function of Stopwatch

Recording Laps:


- Activate the stopwatch.
- O Press the "LAP" button to start the lap record future.
- O When your first LAP is completed and you are ready to record the next simply press the "LAP" button again. Repeat number 4 to record up to 30 LAPs for one work out

Stopping the stop watch at the end of work out:

OPress the "START/STOP" button to pause the stopwatch. Please remember that holding the "START/STOP" button down for 2 or more seconds the memory will be cleared and you will lose the lap records just made.


Recall LAP

O LAP records can store up to LAPs & Recall last 30 LAPs when STOPWATCH was hold



Recalling Recorded Lap Data:

- O Place the Stopwatch on hold (see fig 6 above). O Press the Lap button and Lap record number one will be
- displayed along with the recorded heart rate.
- O Press the Lap button again and both the total Lap time and the the time for Lap one will be displayed.
- After you process number 8, your watch will automatically switch to display the Lap number and Lap time as shown in fig 9. To recall other Lap records repeat number 7 and 8.



Resetting the Stopwatch:

Press and hold the Stop/Start button for 3 seconds TARGET HEART RATE TRAINING GUIDE

50% - 60% Maintain Fitness 60% - 70% Endurance 70% - 80% Slight Resistance

80% - 90% Sustained Resistance

Maximum Pulse Limit (MPL/bpm) = 220-Age For Maintain Fitness TZ setting: Max HR = 60% * MPL Min HR = 50% * MPL

 Targetzone will vary for each individual, depending on Ages, Personal fitness goals, Existing health considerations (High blood pressure, circulation or respiration), Medications and Doctor's recommendations.

AVG Pulse




Show AVG Puls

O The average heart rate will display OFF as long as the Stop watch is cleared

KCAL

O If one did not clear the value of calories by clean time in Stop Watch mode, the value of calories consumption will be accumulated.

Alarm for TZ



• A continuous alarm will sound whenever you exit, either above or below, the programmed target heart rate "zero" An arrow will flash to visually indicate that your heart rate is either above or below the selected target zone. Each press the "light" key, the heart rate reading will "freeze" for 4 seconds.

Recalling Max Heart Rate from Workout



O Press the Mode button 3 times to read the Max heart rate reached during your workout.

Reading the Max heart rate

2

Reset to Zero

BIKE ADAPTOR



MAINTENANCE

The strap can be rinsed in surface fresh water or washed with a mild soap. Never scrape strap to wear out may need to replaced.

2. Transmitter:

Never scrap the rubber electrode surface. The first signs of a worn out transmitter are often erratic heart rate numbers which jump up and down. To extend the life, avoid bending the electrodes.

3.Watch

If the display contrast changes and figures become faint, it's time to replace the watch battery. Consider changing the watch and transmitter batteries at the same time. It's a good practice.

NOTE: Do not expose your Athletic Watch to extremely cold or hot temperatures. For example, do not leave your unit in your car in direct sunligh

4. Batteries and Battery Replacement: Transmitter:

Unscrew the battery cover located on the back of the transmitter Remove the new battery, model CR2032, with the (+) side facing

Replace the cover and tighten screws. Unscrew the four screws on the stainless steel back cover closely at the battery. After removing the housing, Unscrew the inside two small screws located at the 4 o'clock and 8 o'clock positions. Gently remove the battery and replace it with a new battery, model CR2032, the(+) side facing up.

NOTE: Be careful not to over tighten and "strip" the casing.

TROUBLESHOOTING

1. Heart rate does not show up: Make sure that you have good contact between the electrodes and your skin. Re-moiste the electrodes. Make sure your chest belt fits securely and is properly positioned at the center of the chest. The transmitter battery may be worn out. Replace the battery. Make sure the battery is installed correctly with the (+) side facing up.

2. Display is black or very light:

sure the battery is installed correctly. 3. Display becomes dark or black:

The battery power may be low. Try a new battery--make

should return to normal.

4. The unit operates slowly or struggled: The unit is too cold,. Warm the unit, and it should return to normal

The unit is too hot. Place the unit in a shaded area, and it


5. Heart rate varies enormously:


Make sure your chest belt fits securely and is properly positioned at the center of the chest. Check your surroundings for electromagnetic or high energy interference and move away from the source of

LIMITED WARRANTY

This product is for one year limited warranty commencing on the date of purchase. The product will be free from defects in material and workmanship for one year from the date of purchase.

- O Warranty does not cover the batteries, damages due to misuse, abuse or accidents, cracked or broken cases, negligence of precautions, improper maintenance or
- Warranty is void if the repairs are done by non- authorized service technician.
- O The warranties contained herein are expressly in lieu of any other warranties including implied warranty of merchantability and / or fitness for purpose. In no event shall manufacturer be liable for any damages, direct or incidental, consequential or special, arising out of or related to the use of this manual or the products described
- O During this warranty period (one year) the product will either be repaired or replaced without charge.





(B) ----- ↑ & ♣ above or below Target zone.

(C) ----- Alarm ON

(D) ----- Day/Date Calendar

(E) ----- Current HR (F) ----- Flicker When measure HR

